

iphone	kromě iOS v.11 a vyšších verzí <i>a také zařízeních která nemají audio vstup</i>
Acer	Iconia Tab A3
Acer	Iconia Tab A1-810
Acer	Liquid S1 Duo
Acer	Liquid Z3 Duo - Nova - ZX
Acer	Iconia W700P
Acer	Liquid E2 Duo - V370 - C11
Acer	Iconia Tab B1 - A71
Acer	Liquid Z2 Dual
Acer	Liquid E1
Acer	Iconia Tab A210
Acer	Liquid Z110
Acer	CloudMobile S500
Acer	Liquid Gallant Duo - E350
Acer	Liquid Express - E320 - C6
Acer	Liquid Glow - E330
Acer	Iconia Tab A510
Acer	Iconia Tab A700
Acer	Iconia Tab A200
Acer	Allegro - W4 - M310

Acer	Iconia smart - S300
Acer	Liquid E - A1E
Acer	Iconia Tab Wifi - A100
Acer	beTouch E400
Acer	beTouch E120
Acer	beTouch E140
Acer	beTouch E210
Acer	beTouch E130
Acer	Iconia Tab A500 wifi - Picasso
Acer	Liquid Metal - S120 - Liquid mt
Acer	Stream - Liquid S110
Acer	Liquid Mini - E310 - C4
Acer	beTouch E110
Acer	Liquid - S100 - A1
Acer	F900
Acer	M900
Acer	New Touch - S200 - F1
Airness	MK99
Airness	AIR99
Airness	Slide99

Alcatel	One Touch Idol Ultra - OT-6033X - TCL S850
Alcatel	One Touch Scribe Easy - OT-8000D - Scribe5_gsm
Alcatel	One Touch M'Pop - OT-5020D - Megane_GSM
Alcatel	One Touch Idol - OT-6030D
Alcatel	One Touch Star D - OT-6010D
Alcatel	One Touch OT997D - Martell_GSM
Alcatel	One Touch OT585
Alcatel	One Touch OT918D - Dual SIM
Alcatel	One Touch OT995
Alcatel	One Touch OT990
Alcatel	One Touch OT908

Alcatel	One Touch OT918
Alcatel	One Touch OT916
Alcatel	One Touch OT991
Alcatel	One Touch OT990
Alcatel	Text Edition 152 by SFR
Alcatel	OT-980
Alcatel	OT800 - One Touch Tribe
Alcatel	OTV770
Alcatel	OTC701 - Mandarinina Duck
Alcatel	OTS920
Alcatel	OTE101
Alcatel	OTE207
Alcatel	OTE205
Alcatel	OTC550
Alcatel	OT835
Alcatel	OT535
Alcatel	OT355
Alcatel	OTC825
Alcatel	OTC701
Alcatel	OT757
Alcatel	OT525
Alcatel	OT565
Alcatel	OTE259
Alcatel	OTS853
Alcatel	OTC651
Alcatel	OTC552
Alcatel	OT565
Alcatel	ELLE_N1
Alcatel	OT735i
Alcatel	OTE256
Alcatel	OTC750
Amazon	Kindle Fire HDX 8.9

Amazon	Kindle Fire HD (2013)
Amazon	Kindle Fire 7 HDX
Amazon	Kindle Fire HD 8.9
Amazon	Kindle Fire 2 - otter2
Amazon	Kindle Fire HD
Amoi	A500
Apple	iPad 4 - wifi
Apple	iPad Air - wifi
Apple	iPad mini 2 - wifi
Apple	iPhone 5s
Apple	iPad 3 - Wifi
Apple	iPad mini 2 - wifi
Apple	iPod Touch 1
Apple	iPad Air - wifi
Apple	iPhone 5s
Apple	iPhone 5c
Apple	iPad 4 - wifi
Apple	iPad 3 - Wifi
Apple	iPad mini - wifi
Apple	iPod Touch 5
Apple	iPhone 5
Apple	iPhone 4
Apple	iPhone 4S

Apple	iPhone 5
Apple	iPhone 3GS
Apple	iPod Touch 4
Apple	iPod Touch 5
Apple	iPad 4 - wifi
Apple	iPad mini - wifi
Apple	iPad 3 - Wifi
Apple	iPad - wifi
Apple	iPhone 4S
Apple	iPad 2 - Wifi
Apple	iPhone 4S
Apple	iPod Touch 3
Apple	iPhone 4S
Apple	iPhone 3GS
Apple	iPad 2 - Wifi
Apple	iPod Touch 4
Apple	iPod Touch 2
Apple	iPod Touch 4
Apple	iPhone 3GS
Apple	iPhone 3G
Apple	iPhone 3G
Apple	iPad - 3G
Apple	iPhone 4
Apple	iPad 2 - Wifi
Apple	iPhone 3GS
Apple	iPhone 4

Apple	iPhone EDGE
Archos	80 XS
Archos	50 Platinum - A50PL - msm8625
Archos	Arnova 10 - A101B
Archos	GamePad - A70GP
Archos	5 Internet tablet
Archos	Arnova 9 G2
Archos	Arnova 8 G2
Archos	Arnova 7b G2
Archos	101 G8 Internet Tablet
Archos	7 Home Tablet
Archos	70 Internet Tablet
Asus	Nexus 7 (2013) - Flo - Razor
Asus	Transformer Pad Infinity 700 - TF700T
Asus	Transformer Pad 300 - Eee Pad Transformer Prime TF300T

Asus	Nexus 7 (2012) - Nakasi - Grouper
Asus	Eee Pad Slider - SL101
Asus	Eee Pad Transformer Prime - TF201
Asus	Eee Pad - Transformer - TF101
Asus	P526
Asus	P320 GALAXY
Asus	M530w
Asus	P750
Asus	P535
Asus	P525
BenQ	Benq-Siemens S82
BenQ	M300
BenQ	S660C
BenQ	Benq-Siemens S82
BenQ-Siemens	EL71
BenQ-Siemens	EF61
BenQ-Siemens	EF81
BenQ-Siemens	S88
BenQ-Siemens	S68
BenQ-Siemens	EF51
BlackBerry	9720 - Samoa
BlackBerry	Z30 - Aristo
BlackBerry	Q5 LTE - SQR100-2

BlackBerry	Q10 LTE
BlackBerry	Curve 9220
BlackBerry	Z10 - Laguna
BlackBerry	Curve 9320 - SKU1 - SKU2
BlackBerry	Bold 9790 - Bellagio - Onyx III
BlackBerry	Curve Touch 9380 - Orlando
BlackBerry	Bold 9900
BlackBerry	Curve 9360
BlackBerry	Torch 9810
BlackBerry	Torch 9860
BlackBerry	Curve 9360
BlackBerry	Pearl 3G - 9105
BlackBerry	Pearl 8110
BlackBerry	PlayBook
BlackBerry	Curve 3G 9300 - Kepler
BlackBerry	Bold 2 - 9780 - Onyx II
BlackBerry	9800 Torch Slider
BlackBerry	Curve 8320
BlackBerry	Bold 2 - 9780 - Onyx II

BlackBerry	Curve 3G 9300 - Kepler
BlackBerry	9800 Torch Slider
BlackBerry	Storm 2 - 9520
BlackBerry	Curve 8520 - Gemini
BlackBerry	9800 Torch Slider
BlackBerry	Bold 2 - 9700 - Onyx
BlackBerry	Curve 8520 - Gemini
BlackBerry	Curve 8520 - Gemini
BlackBerry	8830
BlackBerry	Curve 8300
BlackBerry	Storm 9500
BlackBerry	Pearl 8120
BlackBerry	Curve 8900 - JAVELIN
BlackBerry	7130v
BlackBerry	Pearl Flip 8220 - KICKSTART
BlackBerry	Storm 9500
BlackBerry	Bold 9000
BlackBerry	Curve 8320
BlackBerry	8820
BlackBerry	8707v

BlackBerry	Pearl 8120
BlackBerry	8800
BlackBerry	Pearl 8100
BlackBerry	7100v - RIM CHARM
BlackBerry	8700v
BlackBerry	7730
BlackBerry	7290
BlackBerry	7230
Carrefour	Smart 5 - CMB501
Dell	Venue - V03B - Thunder
Dell	Venue Pro - V02S - Lightning
Dell	Streak - Mini 5
Dell	Streak 7 - Looking Glass - Opus One
Dell	AXIM X51v
Digi-in	Touch Tablet 8 Neo2 - CT820
Doro	PhoneEasy 740
Doro	PhoneEasy 610
Eten	glofiish X600
Eten	glofiish M810
Eten	glofiish DX900
Fnac	Kobo Arc

Geeksphone	Revolution Firefox
Geeksphone	Revolution Android
GHT	G3
Gigabyte - GSmart	T600
Hannspree	HannSpad - SN10T1
HP	TouchPad - Palm Topaz
HP	Pre 3
HP	iPAQ Voice Messenger
HP	hw6915
HTC	One mini
HTC	Desire 500
HTC	Windows Phone 8X - Accord - C620e
HTC	One - 801n - M7
HTC	One SV - PL80100
HTC	Windows Phone 8S - Rio - A620t
HTC	One X+ - Endeavor C2 - enrc2b
HTC	Desire X - Proto
HTC	Desire C - Golf - A320e

HTC	Sensation XE with Beats Audio - Z715e
HTC	One X - Supreme - S720e - endeavoru
HTC	One V - Primo - T320e
HTC	One S - Ville - Z250E
HTC	ChaCha - PH06110 - A810e - ChaChaCha
HTC	Sensation - Pyramid
HTC	Sensation XL - Runnymede - PI39200
HTC	7 Trophy - T8686 - PC40100 - Spark
HTC	7 Pro - T7576 - PC92100 - Gold
HTC	7 Mozart - T8698 - PD67100
HTC	Titan - X310 - Eternity - PI39110 - Bunyip - Ultimate
HTC	Radar - Omega - PI06100 - C110e

HTC	G1 - DREAM 100
HTC	Radar - Omega - PI06100 - C110e
HTC	Evo 3D - PG86300 - Shooteru
HTC	Titan - X310 - Eternity - PI39110 - Bunyip - Ultimate
HTC	Desire - Bravo - A8181
HTC	Salsa - C510e - PH11110 - Weike
HTC	Sensation - Pyramid
HTC	Flyer Wi-Fi - P512
HTC	Gratia - Aria - A6380 - PB92200 - Liberty
HTC	Wildfire S - PG76110 - A510E - Marvel
HTC	Incredible S - PG32130
HTC	HD7 - T9292 - PD29100 - HD3 - Gold - Diamond3 - Mondrian

HTC	7 Mozart - T8698 - PD67100
HTC	Desire S - S510E - Saga - PG88100
HTC	Desire - Bravo - A8181
HTC	7 Pro - T7576 - PC92100 - Gold
HTC	7 Trophy - T8686 - PC40100 - Spark
HTC	HD2 - T8585 - Leo 100 - PB81100
HTC	Nexus One - passion
HTC	Touch 2 - T3333 - PB74100
HTC	HD7 - T9292 - PD29100 - HD3 - Gold - Diamond3 - Mondrian
HTC	Desire HD - A9191 - Ace
HTC	Desire - Bravo - A8181
HTC	Wildfire - A3333 - Buzz - Bee

HTC	Nexus One - passion
HTC	Legend - A6363
HTC	Tattoo - Click
HTC	Touch Pro2 - T7373 - RHODIUM 100
HTC	S521 - Snap
HTC	Hero
HTC	Touch Diamond2 - T5353 - TOPAZ 100
HTC	Magic (G2) - SAPPHIRE 100
HTC	Touch Cruise 09 - T4242 - IOLITE 100
HTC	P6300 - PANDA
HTC	Touch HD - T8282 - BLACKSTONE 100
HTC	Touch 3G - T3232 - JADE 100
HTC	S740 - ROSE 110
HTC	Touch Viva - T2223 - OPAL 100
HTC	Touch Pro - T7272 - FUZE - RAPHAEL

HTC	G1 - DREAM 100
HTC	P6500 - SEDNA 100
HTC	S730 - WINGS 100
HTC	Touch Diamond - P3700 - Diamond 100
HTC	S710 - VOX - SPV E650
HTC	P4350 - HERALD 100
HTC	P3470 - PHAROS 100
HTC	Touch - P3450 - ELF 100 - Dopod S1
HTC	Touch Dual - P5500 - NIKE 100
HTC	S620 - EXCALIBUR 100
HTC	Touch Cruise - P3650 - POLARIS 100
HTC	TYTN II - P4550 - KAISER 120 - SFR V1615
HTC	P3300 - ARTEMIS 100 - SPV M650

HTC	P3600 - TRINITY 100 - SPV M700 - SFR S300+
HTC	TYTN P4500 - HERMES 200 - SFR v1605
HTC	S620 - EXCALIBUR 100
HTC	S310 - OXYGEN - SPV C100 - Dopod 310
Huawei	Ascend P2
Huawei	Ascend Y300 - U8833-1 - Y300-0100
Huawei	Ascend P6 - U06
Huawei	Ascend G7500
Huawei	Ascend W1 - U00
Huawei	Ascend G615 - U9508
Huawei	Ascend G510 - U8951 - G510-0100
Huawei	Ascend Mate - MT1-U06
Huawei	G6608
Huawei	G6150
Huawei	Ascend G300 - U8815

Huawei	Ideos X3 Blaze - U8510
Huawei	G6600 - Passport
Huawei	Panama- G7210
Huawei	U8150 IDEOS
Huawei	U8180 - Gaga - Ideos X1 - SFR Starshine
Huawei	Ideos x5 - U8800H
Huawei	U8100 - IVY - (Orange) Tactile Internet
Huawei	U8230
Huawei	U526
Huawei	U526
IT Works	TM904
Lenovo	IdeaPad Yoga 13
LG	Optimus Vu II - Vu 2 - F200
LG	G2 - D802
LG	Optimus G Pro
LG	Nexus 5 - hammerhead
LG	Optimus L7 II - L7 2 - P710 - L7X P714
LG	Optimus F5 - P875 - l1e
LG	Optimus L5 II - E460 - E450 - vee5nfc

LG	Optimus True HD LTE - P936 - Maximo - iproj
LG	Optimus L3 II - E430 - E425 - vee3e
LG	Optimus G - E975 - Gee
LG	Nexus 4 - E960 - Mako
LG	Optimus L9 - P760
LG	Optimus Vu - P895
LG	T385
LG	Optimus Chat - C550
LG	Optimus 4X HD - P880 - X3
LG	Prada 3.0 - K2 - P940
LG	Optimus L5 - E610
LG	Optimus L7 - P700
LG	Optimus L3 - E400
LG	E510 - Optimus Hub - Univa
LG	GS290 - Cookie Fresh

LG	KM570 - Cookie Gig - Cookie Music - Surf 4GB - Arena II
LG	GT500 Puccini
LG	C320 - InTouch Lady - Town
LG	GD510 Pop - Twilight - Cookie Pep
LG	Optimus Net - P699 - Optimus Link P690
LG	GT400 - Viewty Smile
LG	Optimus pad - V900 - L06C
LG	Optimus 3D - P920
LG	Optimus Chic - E720
LG	Optimus Me - P350 - Pecan
LG	Optimus 7 - E900
LG	Optimus Black - P970 - Schwarz
LG	A133

LG	Optimus 2X - P990 - Optimus Speed - Star - G2X
LG	GM750 - LAYLA
LG	Optimus One P500
LG	GT540 Optimus - Swift
LG	BL40 New Chocolate
LG	GW520 - Calisto - InTouch Plus - Cookie 3G
LG	GW300 - Onliner - Etna 2 - InTouch Lite
LG	KP550 Rip Curl
LG	GT505
LG	GW620 - Eve
LG	BL20 New Chocolate
LG	GD900 Crystal
LG	GC900 - Viewty Smart
LG	KT610
LG	KF300
LG	KF900 PRADA II
LG	KM500

LG	KM900 - Arena
LG	KC780 - Reina
LG	KB770
LG	KS500
LG	KF900 PRADA II
LG	KP500 - COOKIE
LG	KE590i
LG	KP235
LG	KC910 Renoir
LG	KS360 Etna
LG	KM380
LG	C3320
LG	KC550
LG	KF510
LG	KT520
LG	KF750 Secret
LG	KP130
LG	KP230
LG	KF700
LG	KG375
LG	KE520
LG	G1610
LG	C3100
LG	C3300
LG	C3380
LG	KF600
LG	U8150
LG	KG290
LG	KG800 Chocolate
LG	KU800
LG	KS20 - MS25 - DOMINATOR
LG	KU380
LG	KU990 Viewty
LG	KE500
LG	C1100
LG	KG130
LG	KU970

LG	kg275
LG	kg225
LG	KU580
LG	KG220
LG	KP202
LG	KE800
LG	KE850 Prada
LG	KU311
LG	U8330i
LG	KE970 - Shine
LG	KU800
LG	KG810
LG	L1100
LG	KG320
LG	L600v
LG	U8210
LG	F2100
LG	KU730
LG	5300i
LG	U8120
LG	KG220
LG	B2100
LG	C3310
LG	F2400
LG	KG800 Chocolate
LG	M6100
LG	S5200
LG	U8500
LG	U8290
LG	P7200
LG	C1100
LG	G5400
LG	C1150
Logicom	TAB 1050
Microsoft	Surface Tablet RT
Mio	A701
Modelabs	MTV 3.4
Modelabs	Levis The Original 3G
Modelabs	MTV 3.3
Modelabs	MTV 3.0

Modelabs	Elite eML2
Motorola	Moto G - XT1032 - DVX
Motorola	RAZR i - XT890
Motorola	Moto G - XT1032 - DVX
Motorola	Droid PRO - XT610
Motorola	Motosmart XT389 - Motoluxe XT389 - argonmini_umts
Motorola	EX112
Motorola	Razr HD - XT925 - Vanquish
Motorola	RAZR i - XT890
Motorola	Gleam Plus +
Motorola	Xoom 2 - MZ615 - XYBOARD 10.1
Motorola	Xoom 2 Media Edition - MZ607 - XYBOARD 8.2
Motorola	Razr - XT910 - Spyder
Motorola	Motoluxe
Motorola	Defy Mini - XT320
Motorola	Gleam
Motorola	Wilder - EX130

Motorola	Fire XT311
Motorola	Atrix - Olympus - ME860
Motorola	Milestone 2 - Droid 2 - A953
Motorola	XOOM Wifi - MZ604 - wingray
Motorola	Defy - MB525 - Jordan
Motorola	XOOM Wifi - MZ604 - wingray
Motorola	Flipout MB511
Motorola	Milestone XT720 - MOTOROI
Motorola	Backflip MB300 - Enzo - Motus
Motorola	Milestone - Droid - Sholes
Motorola	DEXT MB220 - CLIQ - Morrison
Motorola	V360
Motorola	Mpx220
Motorola	U9 MOTOJEWEL
Motorola	EM325 - EM25
Motorola	W388
Motorola	ZINE ZN5

Motorola	V6 RAZR MAXX Ferrari Challenge
Motorola	W180
Motorola	W218
Motorola	W208
Motorola	E398
Motorola	W230
Motorola	ROKR E8
Motorola	KRZR K3
Motorola	C139
Motorola	C550
Motorola	T720
Motorola	A835
Motorola	A920
Motorola	U9
Motorola	Q9
Motorola	W377
Motorola	L7e
Motorola	ROKR Z6
Motorola	RIZR Z8
Motorola	C650
Motorola	RAZR2 V8
Motorola	V3r Pink
Motorola	SLVR L9 / L72
Motorola	A1000
Motorola	V3v
Motorola	E365
Motorola	E770v
Motorola	ROKR Z6
Motorola	E1000
Motorola	V980
Motorola	V635
Motorola	A910
Motorola	L2
Motorola	W510
Motorola	W510
Motorola	MOTOFONE F3
Motorola	W375
Motorola	E365
Motorola	W220
Motorola	V3xx
Motorola	RIZR Z3
Motorola	V220
Motorola	V3

Motorola	KRZR K1
Motorola	V180
Motorola	V525
Motorola	V1050
Motorola	V1075 (E1070)
Motorola	E770v
Motorola	C450
Motorola	V400p
Motorola	V600
Motorola	V547
Motorola	V975
Motorola	V600
Motorola	V551
Motorola	V550
Motorola	V500
Motorola	V3x - V1150
Motorola	V3i
Motorola	V3c
Motorola	V360v
Motorola	V300
Motorola	ROKR E1
Motorola	PEBL U6
Motorola	SLVR L7
Motorola	L6
Motorola	C390
MyWay	allure
NEC	N500i
NEC	n22i
NEC	N401i
NEC	N341i
NEC	342i
Nokia	Lumia 1020 - EOS 909 - RM-875 - RM-877 - RM-876
Nokia	Asha 501
Nokia	Lumia 625 LTE
Nokia	C2-05 Touch and Type
Nokia	Lumia 720
Nokia	113

Nokia	C2-02 - Touch and Type
Nokia	Lumia 520
Nokia	Lumia 510
Nokia	Lumia 620
Nokia	Asha 200
Nokia	Lumia 920 - Nokia Phi
Nokia	Lumia 820 - Nokia Arrow
Nokia	Lumia 920 - Nokia Phi
Nokia	Asha 305 - Asha 3050
Nokia	Asha 202
Nokia	113
Nokia	112
Nokia	Asha 300
Nokia	808 PureView - 803
Nokia	Asha 306
Nokia	Lumia 900 - Ace
Nokia	Asha 302
Nokia	Asha 311
Nokia	Asha 303
Nokia	Lumia 900 - Ace
Nokia	Lumia 610
Nokia	Asha 303
Nokia	Lumia 710 - Sabre
Nokia	Lumia 800 - Sea Ray

Nokia	Lumia 800 - Sea Ray
Nokia	701
Nokia	700
Nokia	E6-00
Nokia	E5-00
Nokia	2710 Navigation Edition
Nokia	6303i classic
Nokia	E6-00
Nokia	5330 Mobile TV Edition
Nokia	c7-00
Nokia	X7-00
Nokia	1616-2
Nokia	C3-01
Nokia	C3-00
Nokia	C3-00
Nokia	2323 classic
Nokia	2720 fold
Nokia	C2-01
Nokia	2700 classic
Nokia	6303i classic
Nokia	C3-01
Nokia	E72-1
Nokia	3710 fold
Nokia	5228
Nokia	X3-02
Nokia	C6-01 / C6-01.3
Nokia	3720 classic / 3720c-2
Nokia	N8-00
Nokia	E7-00
Nokia	C5-03
Nokia	C6-00
Nokia	C1-02
Nokia	C2-01
Nokia	C1-01
Nokia	1800

Nokia	2730 classic / 2730c-1
Nokia	2220 slide / 2220s
Nokia	1209
Nokia	1662-2
Nokia	5030 XpressRadio / 5030c-2
Nokia	N86 8MP / N86-1
Nokia	N97-1
Nokia	5250
Nokia	N8-00
Nokia	c7-00
Nokia	E72-1
Nokia	E72-1
Nokia	C6-00
Nokia	6720 classic / 6720c
Nokia	E52-1
Nokia	X3-00
Nokia	X2-00
Nokia	7020a-2
Nokia	X3-00
Nokia	C5-00
Nokia	2690
Nokia	E55-1
Nokia	6700 Slide
Nokia	5730 XpressMusic / 5730s-1
Nokia	5530 XpressMusic
Nokia	6710 Navigator
Nokia	6710 Navigator
Nokia	N900 - Rover

Nokia	N900 - Rover
Nokia	X6-00 - Alvin
Nokia	N97 Mini / N97-4
Nokia	7230
Nokia	7230
Nokia	5230
Nokia	5230
Nokia	5230
Nokia	6210 Navigator / 6210s-1
Nokia	2330 Classic / 2330c-2
Nokia	3120 classic / 3120c-1
Nokia	E75-1
Nokia	N86 8MP / N86-1
Nokia	N86 8MP / N86-1
Nokia	6700 classic / 6700c-1
Nokia	N97-1
Nokia	N97-1
Nokia	1100
Nokia	3110 Classic / 3110c
Nokia	8800 Carbon Arte
Nokia	5630 XpressMusic / 5630d-1
Nokia	N75-3
Nokia	2330 Classic / 2330c-2
Nokia	7650

Nokia	5130 XpressMusic / 5130c-2
Nokia	3610 Fold / 3610a
Nokia	7510 Supernova / 7510a
Nokia	6600 Slide / 6600s-1c
Nokia	6300i
Nokia	7100 Supernova - 7100s-2
Nokia	7070 Prism / 7070d-2
Nokia	E63-1
Nokia	5220 XpressMusic
Nokia	5800 XpressMusic / 5800d-1
Nokia	N85-1
Nokia	5320 XpressMusic / 5320d-1
Nokia	6212 Classic (NFC) / 6212c
Nokia	6600 fold / 6600f-1
Nokia	N79-1
Nokia	7210 Supernova / 7210c
Nokia	N73-1
Nokia	E66-1
Nokia	N96-1

Nokia	6124 Classic / 6124c-1
Nokia	5070
Nokia	7610 Supernova / 7610s
Nokia	2680 Slide / 2680s-2
Nokia	E71-1
Nokia	3600 Slide / 3600s
Nokia	3120 classic / 3120c-1c
Nokia	7310 Supernova / 7310c
Nokia	2600 classic / 2600c-2
Nokia	2626
Nokia	E90-1
Nokia	6210 Navigator / 6210s-1
Nokia	6131 NFC
Nokia	6131 NFC
Nokia	3510i
Nokia	5000d-2
Nokia	6220 Classic / 6220c-1
Nokia	7900 Prism / 7900d-1
Nokia	6555
Nokia	N78-1
Nokia	E51-1
Nokia	1600
Nokia	2310
Nokia	6810
Nokia	6610i
Nokia	N82-1
Nokia	6610

Nokia	5100
Nokia	7210
Nokia	6267
Nokia	6800
Nokia	N81-1
Nokia	N77-1
Nokia	8600 Luna - 8600d
Nokia	6301
Nokia	3310
Nokia	6680
Nokia	6500 Slide / 6500s-1
Nokia	6020
Nokia	5310 XpressMusic
Nokia	5200
Nokia	3109 Classic / 3109c
Nokia	3500 Classic / 3500c
Nokia	E61-1
Nokia	N95 8GB / N95-2
Nokia	2760
Nokia	N93i-1
Nokia	5610 XpressMusic / 5610d-1
Nokia	6500 Classic / 6500c
Nokia	3310
Nokia	3110 Classic / 3110c
Nokia	3110
Nokia	6260
Nokia	6670
Nokia	7610
Nokia	2630
Nokia	5310 XpressMusic

Nokia	6630
Nokia	N95-1
Nokia	6233
Nokia	N76-1
Nokia	6280
Nokia	6234
Nokia	N73-1
Nokia	6151
Nokia	6131
Nokia	6290
Nokia	7500 Prism
Nokia	3100
Nokia	2600
Nokia	6110 Navigator
Nokia	6120 Classic / 6120c-1
Nokia	3510i
Nokia	6070
Nokia	5700 XpressMusic
Nokia	E61i-1
Nokia	6080
Nokia	6280
Nokia	5200
Nokia	N95-1
Nokia	6086
Nokia	6085
Nokia	6300
Nokia	E65-1
Nokia	6288
Nokia	2652
Nokia	7390
Nokia	N70-1
Nokia	6234
Nokia	6680
Nokia	E50-2
Nokia	7373
Nokia	5300
Nokia	6136
Nokia	6681
Nokia	6170
Nokia	6131
Nokia	3120
Nokia	2610
Nokia	6820a

Nokia	6234
Nokia	3660
Nokia	6020
Nokia	6280
Nokia	6070
Nokia	6230b
Nokia	3230
Nokia	6030
Nokia	N93-1
Nokia	E70-1
Nokia	N71-1
Nokia	6233
Nokia	E60-1
Nokia	N72-5
Nokia	9300i
Nokia	9500
Nokia	5500d
Nokia	N-Gage QD
Nokia	7710
Nokia	6100
Nokia	7270
Nokia	6270
Nokia	2650
Nokia	7260
Nokia	6125
Nokia	5140i
Nokia	N91-1
Nokia	3100
Nokia	3220
Nokia	N-Gage
Nokia	N90-1
Nokia	N80-1
Nokia	8800
Nokia	7650
Nokia	7370
Nokia	7360
Nokia	6822
Nokia	6680
Nokia	6630
Nokia	6600
Nokia	6230i
Nokia	6111
Nokia	6103
Nokia	6101
Nokia	6060
Nokia	6021
Nokia	3650
Nokia	3410

Orange	Intel Inside - Santa Diego - Santa Clara - Intel Black Ray - AZ210B
Orange	SPV - HTC CANARY
Orange	SPV C500 - HTC TYPHOON - Qtek 8010
Orange	SPV C200 - Amoi E72
Orange	SPV M2000 - HTC BLUE ANGEL - Qtek 9090
Orange	SPV C600 - HTC FARADAY
Orange	SPV M2000 - HTC BLUE ANGEL - Qtek 9090
Orange	SPV M3100 - HTC HERMES 100 - Qtek 9600
Orange	SPV E200 - HTC VOYAGER - Qtek 8080
Palm	Pre 2
Palm	Pixi Plus

Palm	Pre Plus - P101
Palm	Pre Plus - P101
Palm	Centro
Palm	Treo 650
Palm	Treo Pro
Palm	Treo 750v
Palm	Treo 500
Palm	Centro
Palm	Tungsten E2
Palm	Tungsten T5
Palm	Treo 680
Panasonic	Eluga dL1 - EB-3901
Panasonic	GD87
Panasonic	X60
Panasonic	P341i
Panasonic	VS6
Panasonic	VS3
Pantech	U4000
Pantech	U4000
Pantech	PG3900
Pantech	PG1200
Polaroid	Tablet Diamond III
Polaroid	Pro G160
Polaroid	PROA54BPR003
Qilive	Tablet 9.7
Qtek	8100 - HTC AMADEUS
Qtek	S200 - HTC PROPHET - SPV M600

Qtek	9100 - HTC WIZARD P4300 - SPV M3000
Qtek	S200 - HTC PROPHET - SPV M600
Qtek	2020 - HTC HIMALAYA - SPV M1000
Qtek	8020 - HTC FEELER
Qtek	8300 - HTC TORNADO
Sagem	Cosy Phone
Sagem	VF540
Sagem	PUMA Phone - M1
Sagem	my810X
Sagem	My521X
Sagem	My850v
Sagem	My750x ROXY
Sagem	My421z
Sagem	MyX7
Sagem	My230V
Sagem	my519x
Sagem	my312x
Sagem	MyX3-2
Sagem	My332v
Sagem	My730C
Sagem	my721x
Sagem	my220x
Sagem	My401z
Sagem	MyC3-2
Sagem	My201X
Sagem	my501x
Sagem	My411X RG512

Sagem	my810X
Sagem	My101x
Sagem	MyC4-2
Sagem	my600x
Sagem	myx5-2m
Sagem	My411cv
Sagem	my511X
Sagem	MyX5
Sagem	my800v
Sagem	MyW7
Sagem	MyW8
Sagem	myx5m
Sagem	My419x
Sagem	My600v
Sagem	My700xi
Sagem	My411v
Sagem	My411x
Sagem	My401c
Sagem	My212x
Sagem	my202c
Sagem	my600x
Sagem	MyC5-3
Sagem	my501c
Sagem	My405x
Sagem	MyV65
Sagem	MyC4-2
Sagem	MyV76
Sagem	MyC4
Sagem	MyV55
Sagem	My700x
Sagem	My301x
Sagem	My300x
Sagem	My302x
Sagem	MyX5-2t
Sagem	SG341i
Sagem	MyV56
Sagem	MyZ5
Sagem	MyX8
Sagem	MyC5-2
Sagem	My400v
Sagem	MyX6-2
Sagem	MyS7
Sagem	My401x
Samsung	Galaxy Fame Lite - S6790N
Samsung	Galaxy Core Plus

Samsung	Galaxy S3 - Galaxy SIII - i9300
Samsung	Galaxy Ace III LTE - Galaxy Ace 3 LTE - S7275R
Samsung	Galaxy Note 3 - N9005
Samsung	Galaxy S Plus
Samsung	Galaxy Tab 3 7.0 WiFi - SM-T210
Samsung	Galaxy Tab 3 8.0 - SM T310
Samsung	Galaxy Tab 3 10.1 - P5210 - santos10wifi
Samsung	Galaxy Young - S6310
Samsung	Galaxy S4 Active - i9295 - jactivelte
Samsung	Galaxy Trend - S7560 - kylessopen
Samsung	Galaxy Core Duos - i8262 - arubaslim

Samsung	Galaxy S4 Zoom - SM-C101 - SM-C1010 - mproject3g
Samsung	Galaxy Mega 6.3 LTE - i9205 - meliuslte
Samsung	Galaxy S4 mini LTE - i9195 - serranolte
Samsung	Galaxy S4 - i9500 - Altius
Samsung	Galaxy Fame - S6810P - nevisp
Samsung	Galaxy Note 8.0 - N5110 - Galaxy Note 511 - Galaxy Note 8 WiFi
Samsung	Galaxy Xcover 2 - S7710 - skomer
Samsung	Galaxy Express - i8730 - expresslte
Samsung	Galaxy Pocket - S5300

Samsung	Galaxy Grand Duos - i9082 - Baffin
Samsung	Nexus 10 - P8110 - manta
Samsung	Galaxy S II LTE - SC-03D
Samsung	Galaxy S II Plus - Galaxy S2 Plus - i9105
Samsung	GT-B5722
Samsung	Galaxy S II Cityzi - Galaxy S2 NFC - i9100P
Samsung	GT-E2530
Samsung	ATIV S - I8750 - Odyssey
Samsung	Galaxy S III Mini - Galaxy S3 Mini - i8190 - golden
Samsung	Galaxy S Duos - S7562
Samsung	Star 3 s5220 - Tocco Lite 2
Samsung	Galaxy Camera - GC100
Samsung	Galaxy Note II - Galaxy Note 2 - N7100
Samsung	Monte Slider - GT-E2550

Samsung	GT-E2330
Samsung	Galaxy Tab 7.0 Plus - P6210
Samsung	C3520 - La Fleur
Samsung	C3750 - Metro 3752
Samsung	Galaxy Ace Duos - S6802
Samsung	Player Mini - Champ - C3300K - C3303 - Libre
Samsung	Player Mini 2 - GT C3310
Samsung	Galaxy Note 10.1 - N8000 - Galaxy Note 800
Samsung	Galaxy Beam - i8530
Samsung	Galaxy S Advance NFC - i9070P
Samsung	Player City - GT S5260P
Samsung	Galaxy Tab 2 10.1 - P5110 - espresso10wifi
Samsung	Galaxy Mini 2 - S6500 - Jena

Samsung	Galaxy Ace II - Galaxy Ace 2 - i8160
Samsung	Galaxy Tab 2 7.0 - P3110 - espressowifi
Samsung	Galaxy Tab 8.9 - P7310
Samsung	Galaxy Ace Plus - S7500
Samsung	Galaxy Y Duos - S6102
Samsung	Wave M - S7250 - Wave725
Samsung	Galaxy Nexus - i9250 - Google Nexus 3 - maguro
Samsung	Galaxy Tab 7.7 - P6810
Samsung	Wave Y - S5380 - Wave 538
Samsung	Galaxy Y - S5360
Samsung	Omnia W - i8350
Samsung	Galaxy Note - N7000 - i9220
Samsung	Galaxy Nexus - i9250 - Google Nexus 3 - maguro

Samsung	Wave 3 - S8600
Samsung	M5650 - Lindy - Player MTV
Samsung	GT-B2710
Samsung	C5130
Samsung	Galaxy SL - Galaxy SCL - i9003
Samsung	Galaxy Tab 10.1 - P7510
Samsung	Galaxy S II - Galaxy S2 - i9100 - Attain
Samsung	Star II - S5260
Samsung	Wave 578 - S5780
Samsung	Player One Cityzi - GT S5230N
Samsung	Galaxy Gio - S5660
Samsung	Wave 525- S5250
Samsung	Galaxy Naos - i5801 - Galaxy Leo - Galaxy Apollo
Samsung	Galaxy Pro - B7510
Samsung	E1150

Samsung	Galaxy 551 - i5510
Samsung	CorbyPro B5310 - Genio Slide - Brooklyn
Samsung	B3410 - CorbyPlus - Delphi
Samsung	Galaxy S II - Galaxy S2 - i9100 - Attain
Samsung	Nexus S - i9023 - Crespo
Samsung	Chat S3350
Samsung	Galaxy Mini - S5570 - tass
Samsung	Galaxy Ace - S5830 - Cooper
Samsung	Wave 723 - S7230E
Samsung	Galaxy Tab - P1000
Samsung	i8910 Omnia HD
Samsung	Wave 575 - S5750E
Samsung	Wave 533 - S5330
Samsung	Wave II - S8530

Samsung	S7070 - Miss Player - Diva
Samsung	Nexus S - i9023 - Crespo
Samsung	CorbyTXT B3210
Samsung	OmniaPRO B7610 - Louvre
Samsung	Wave II - S8530
Samsung	Omnia 7 - i8700
Samsung	Galaxy 550 - i5500 - Galaxy 5 - Corby Smartphone - Europa
Samsung	Galaxy S - i9000
Samsung	S5620 - Player Star 2 - MONTE - Onix - Kabuki
Samsung	Galaxy Spica - i5700 - Galaxy Lite
Samsung	Galaxy Teos - i5800 - Galaxy 3 - Galaxy 580
Samsung	S5560 - Player 5 - Star WiFIVE
Samsung	S8000 Jet
Samsung	Wave - S8500

Samsung	Wave - S8500
Samsung	S3100 - Croy
Samsung	C3510 Player Light - Corby Pop - Genoa
Samsung	B2100 Xplorer - Solid Extreme - Marine
Samsung	Omnia Lite B7300
Samsung	OMNIAII - i8000 - WiTu
Samsung	Galaxy Spica - i5700 - Galaxy Lite
Samsung	Galaxy - i7500
Samsung	B3310 Nox - Corby Mate
Samsung	C3050
Samsung	S3650 Corby - Genio
Samsung	S5600 - Player Star - PRESTON
Samsung	M3510 BEAT b
Samsung	X550
Samsung	P250
Samsung	M7600 - Platine - Beat DJ
Samsung	E200
Samsung	J400

Samsung	M7500 - Emporio Armani Night Effect
Samsung	S7350 - Ultra S
Samsung	S5230 - Player One - TOCCO LITE
Samsung	E200 Eco
Samsung	J770 - F268
Samsung	S3600
Samsung	S3030 - Tobi
Samsung	L310
Samsung	S8300 - Player Ultra - ULTRATOUCH
Samsung	L810v - STEEL
Samsung	C6625
Samsung	M620
Samsung	S7330
Samsung	i8510 INNOV8
Samsung	D980 Dual Sim
Samsung	M3200 Pussycat Dolls
Samsung	i900 - Player Addict - OMNIA
Samsung	D500
Samsung	M310 - Slash
Samsung	L700
Samsung	E600
Samsung	J800 Luxe
Samsung	M8800 - Player Pixon

Samsung	G400 Soul
Samsung	U800 Soul b
Samsung	F480 - Player Style - TOCCO
Samsung	L600
Samsung	i550
Samsung	i200
Samsung	F210
Samsung	U100
Samsung	E590
Samsung	G810
Samsung	P220
Samsung	F480 - Player Style - TOCCO
Samsung	F400
Samsung	D780 Dual Sim
Samsung	L770
Samsung	F110 Adidas miCoach
Samsung	X160
Samsung	i320
Samsung	C520
Samsung	i450
Samsung	L170
Samsung	F250
Samsung	i710
Samsung	i620
Samsung	i560v
Samsung	D880 Dual Sim
Samsung	P520 - Giorgio Armani
Samsung	U900
Samsung	V200
Samsung	E710
Samsung	P400
Samsung	M610
Samsung	S720i
Samsung	S500i
Samsung	F490
Samsung	J700

Samsung	F330
Samsung	M110
Samsung	i780
Samsung	P180
Samsung	A800
Samsung	J750
Samsung	E950
Samsung	X660V
Samsung	E740
Samsung	E250
Samsung	D500
Samsung	Z140V
Samsung	Z170
Samsung	F700
Samsung	P260
Samsung	G800
Samsung	E950
Samsung	Z310
Samsung	G600
Samsung	ZV50
Samsung	L760
Samsung	P910
Samsung	E800
Samsung	X490
Samsung	Z510
Samsung	D900i
Samsung	Z400
Samsung	X700
Samsung	S500
Samsung	X660
Samsung	ZV40
Samsung	I600
Samsung	ZV50
Samsung	Z540
Samsung	Z560V
Samsung	C260
Samsung	ZV60
Samsung	M300
Samsung	E790
Samsung	z240e
Samsung	Z630
Samsung	x530
Samsung	E840
Samsung	i320
Samsung	E740
Samsung	J600
Samsung	U600
Samsung	U700
Samsung	I600
Samsung	Z720

Samsung	X650
Samsung	F300
Samsung	Z360
Samsung	X830
Samsung	Z150
Samsung	D840
Samsung	C300
Samsung	D600E
Samsung	E390
Samsung	E570
Samsung	E250
Samsung	E250
Samsung	Z650i
Samsung	X510
Samsung	Z560
Samsung	P310
Samsung	P200
Samsung	D730
Samsung	E310
Samsung	E780
Samsung	Z230
Samsung	E340
Samsung	Z107V
Samsung	E810
Samsung	E720
Samsung	D830
Samsung	ZV40
Samsung	E850
Samsung	X500
Samsung	X460
Samsung	X450
Samsung	Z400v
Samsung	E330
Samsung	ZV50
Samsung	ZV10
Samsung	X680
Samsung	Z540V
Samsung	E300
Samsung	ZV30
Samsung	E700
Samsung	D900
Samsung	X820
Samsung	E530
Samsung	E370
Samsung	D500E
Samsung	S341i
Samsung	Z500v
Samsung	Z300
Samsung	Z140V
Samsung	X810

Samsung	X660V
Samsung	X640
Samsung	X600
Samsung	X480
Samsung	X300
Samsung	X200
Samsung	p300
Samsung	i300
Samsung	E900
Samsung	E880
Samsung	E860v
Samsung	E770
Samsung	E730
Samsung	E630
Samsung	E620
Samsung	E350E
Samsung	D820
Samsung	D800
Samsung	D720
Samsung	D600
Samsung	D520
Samsung	E360
Sanyo	S750i
Sendo	SV663
Sendo	M570
SFR	Starxtrem
SFR	Staraddict 2 Plus
SFR	Staraddict 2
SFR	Startext II
Sharp	Aquos Phone - SH-01D
Sharp	550SH
Sharp	903SH
Sharp	GX15
Sharp	GX30
Sharp	GX20
Sharp	770SH
Sharp	GX25
Sharp	GX29
Sharp	GX17
Sharp	902SH
Siemens	SL75
Siemens	S75
Siemens	S65
Siemens	SXG75

Siemens	S55
Siemens	AL21
Siemens	AX72
Siemens	MC60
Siemens	C65V
Siemens	C75
Siemens	C72
Siemens	M65
Siemens	SXG75
Siemens	A65
Siemens	SK65
Siemens	ME75
Siemens	CX75
Siemens	CL75
Siemens	CF110
Siemens	C75
Siemens	CX65
Sony	Xperia Z1 Compact - D5503
Sony	Xperia SP - LTE C5303
Sony	Xperia Z Ultra - C6833
Sony	Xperia GX - SO-04D
Sony	Xperia Z1 - C6903
Sony	Xperia M - C1904 - C1905 - Nicki SS
Sony	Xperia Tablet Z WiFi - SGP311 - SGP312 - C6907 - Pollux
Sony	Xperia L - S36h - C2105 - TaoShan
Sony	Xperia Z - L36i - C6603 - Yuga

Sony	Xperia V - LT25i - Tsubasa
Sony	Xperia E Dual - C1605
Sony	Xperia J - ST26i - JLo
Sony	Xperia T - LT30p - The Bond Phone - Mint Rita
Sony	Xperia Miro - ST23i - Mesona
Sony	Xperia Tipo Dual - ST21i2 - Tapioca DS
Sony	Tablet P 3G - S2
Sony	Xperia tipo - ST21i - Tapioca
Sony	Xperia ion - Lt28h - aoba
Sony	Xperia Go - ST27i - Xperia Advance - Lotus
Sony	Xperia U - ST25i - Kumquat
Sony	Xperia P - LT22i - Nyphon

Sony	Xperia Sola - MT27i Pepper
Sony	Xperia S - LT26i - Arc HD - Nozomi
Sony	Tablet S
Sony Ericsson	Xperia Acro HD SO-03D - Hikari
Sony Ericsson	Xperia Kyno (Neo) - MT15i - Hallon
Sony Ericsson	Xperia Kyno (Neo) - MT15i - Hallon
Sony Ericsson	Xperia X8 - E15i - Shakira
Sony Ericsson	K810i
Sony Ericsson	Txt - CK13i
Sony Ericsson	txt pro - CK15i
Sony Ericsson	Yendo - W150i - TeaCake - Yizo
Sony Ericsson	Aspen - Faith - M1i
Sony Ericsson	Elm - GreenHeart - J10i2
Sony Ericsson	Xperia Arc S - LT18i
Sony Ericsson	Zylo - W20i

Sony Ericsson	Xperia Pro - MK16i - iyokan
Sony Ericsson	Xperia mini - ST15i - smultron
Sony Ericsson	Xperia Ray - Urushi - ST18i
Sony Ericsson	Xperia active - ST17i - Satsuma
Sony Ericsson	Xperia mini pro - XPERIA X10 mini pro2 - SK17i - mango
Sony Ericsson	Hazel - J20i
Sony Ericsson	Xperia Kyno (Neo) - MT15i - Hallon
Sony Ericsson	Vivaz Pro - Kanna - U8i
Sony Ericsson	Yari - U100i
Sony Ericsson	Spiro - w100i
Sony Ericsson	Vivaz - U5i - Kurara
Sony Ericsson	Xperia PLAY - R800i - Zeus
Sony Ericsson	Xperia Arc - LT15i - Anzu - X12

Sony Ericsson	Xperia Kyno (Neo) - MT15i - Hallon
Sony Ericsson	Xperia X10 - Rachael - es209ra
Sony Ericsson	Xperia X8 - E15i - Shakira
Sony Ericsson	Xperia X10 mini pro - U20i - mimmi
Sony Ericsson	Xperia X10 mini pro - U20i - mimmi
Sony Ericsson	Xperia X10 mini pro - U20i - mimmi
Sony Ericsson	Xperia X10 mini - E10i - Robyn
Sony Ericsson	Xperia X10 - Rachael - es209ra
Sony Ericsson	Satio - Idou - U1i
Sony Ericsson	W995
Sony Ericsson	C903
Sony Ericsson	Z750i
Sony Ericsson	W508
Sony Ericsson	T707
Sony Ericsson	C901

Sony Ericsson	W715
Sony Ericsson	W395
Sony Ericsson	W705
Sony Ericsson	C510
Sony Ericsson	G705u
Sony Ericsson	R306
Sony Ericsson	W302
Sony Ericsson	K330
Sony Ericsson	W902
Sony Ericsson	S302 Snapshot
Sony Ericsson	C905
Sony Ericsson	F305
Sony Ericsson	W595
Sony Ericsson	T700
Sony Ericsson	XPERIA X1
Sony Ericsson	K618i
Sony Ericsson	G502
Sony Ericsson	T303
Sony Ericsson	Z250i
Sony Ericsson	R300
Sony Ericsson	Z770i
Sony Ericsson	W980
Sony Ericsson	G900
Sony Ericsson	T280i
Sony Ericsson	W960i - Mooi

Sony Ericsson	W760i
Sony Ericsson	C902
Sony Ericsson	T650i
Sony Ericsson	Z555i
Sony Ericsson	Z320i
Sony Ericsson	G700
Sony Ericsson	C702i
Sony Ericsson	W350i
Sony Ericsson	W890i
Sony Ericsson	K660i
Sony Ericsson	k320i
Sony Ericsson	W380i
Sony Ericsson	P900
Sony Ericsson	V630i
Sony Ericsson	W910i
Sony Ericsson	Z710i
Sony Ericsson	K530i
Sony Ericsson	V640i - K630i
Sony Ericsson	P910i
Sony Ericsson	Z800i
Sony Ericsson	T68i
Sony Ericsson	S500i
Sony Ericsson	Z600
Sony Ericsson	Z1010
Sony Ericsson	p1i

Sony Ericsson	K770i
Sony Ericsson	W910i
Sony Ericsson	K850i
Sony Ericsson	M600i
Sony Ericsson	W580i
Sony Ericsson	W660i
Sony Ericsson	W580i
Sony Ericsson	W850i
Sony Ericsson	W200i
Sony Ericsson	K810i
Sony Ericsson	K510i
Sony Ericsson	k320i
Sony Ericsson	W950i
Sony Ericsson	W610i
Sony Ericsson	K550i
Sony Ericsson	Z310i
Sony Ericsson	Z300i
Sony Ericsson	Z710i
Sony Ericsson	K608i
Sony Ericsson	W810i
Sony Ericsson	W710i
Sony Ericsson	Z610i
Sony Ericsson	W850i
Sony Ericsson	Z550i
Sony Ericsson	P990i

Sony Ericsson	W800i
Sony Ericsson	V800
Sony Ericsson	V630i
Sony Ericsson	W300i
Sony Ericsson	K610i
Sony Ericsson	K510i
Sony Ericsson	K310i
Sony Ericsson	W900i
Sony Ericsson	S700i
Sony Ericsson	K700i
Sony Ericsson	K500i
Sony Ericsson	K300i
Sony Ericsson	M600i
Sony Ericsson	K800i
Sony Ericsson	T630
Sony Ericsson	Z520i
Sony Ericsson	P800
Sony Ericsson	J300i
Sony Ericsson	Z530i
Sony Ericsson	W700i
Sony Ericsson	W550i
Sony Ericsson	W600i
Sony Ericsson	T610
Sony Ericsson	K750i
Sony Ericsson	V600i

Sony Ericsson	K600i
Sony Ericsson	F500i
Thomson	X-Link 4.0 - TH-1127M
Thomson	Xview 2 - TH II29M
Toshiba	AT300 - Excite 10 SE
Toshiba	AT100 - Thrive
Toshiba	Folio 100 wifi
Toshiba	TG01
Toshiba	G910 / G920 - PORTEGE
Toshiba	G450
Toshiba	G810 PORTEGE
Toshiba	TS605
Toshiba	TS705
Toshiba	G710 PORTEGE
Toshiba	G900 PORTEGE
Toshiba	TS705
Toshiba	TS705
Toshiba	TS608
Toshiba	TS803
ViewSonic	ViewPad 10s
ViewSonic	ViewPad 7
VK Mobile	VK4000
VK Mobile	VK2020
VK Mobile	VK2010
VK Mobile	VK4500
VK Mobile	VK700
Wiko	Sublim
Wiko	Darknight

Wiko	Darkfull
Wiko	Darkmoon
Wiko	Iggy
Wiko	Ozzy
Wiko	DarkSide
Wiko	Stairway
Wiko	Cink Peax 2
Wiko	Cink Five
Wiko	Cink+
Wiko	Cink Slim - S8073
Wiko	Cink Peax
Wiko	Cink King - S9081
Wiko	Cink - S8030 - Dual Sim
Wonu	S1
Wonu	S3
Xiaomi	MI-2s
ZTE	Open
ZTE	Blade III - Blade 3 - atlas40
ZTE	F160
ZTE	Cute - G-N281 - Vairy Touch II - Tactile Musique
ZTE	Racer II
ZTE	R620
ZTE	Light Tab 2 - V9A
ZTE	Windows Phone SFR Internet 7 - Tania - Spirit
ZTE	Android Edition by SFR STARADDICT

ZTE	Blade S - Crescent - (Orange) San Francisco II
ZTE	Cute - G-N281 - Vairy Touch II - Tactile Musique
ZTE	Messenger Edition 251 by SFR
ZTE	Orange Tactile messaging - P671A80
ZTE	S by SFR 342
ZTE	Text Edition 151 by SFR
ZTE	S by SFR 344
ZTE	Messenger Edition 261 by SFR
ZTE	Skate - Orange Monte Carlo
ZTE	Android Edition Starnaute
ZTE	StarTrail Android Edition (SFR)

ZTE	Blade - P729B - (Orange) Tactile internet 2 - San Francisco
ZTE	Link
ZTE	e810 - SFR 551
ZTE	X760 - (ORANGE) Le Tactile Roland Garros - (SFR) 341